



# INSTRUCTION

## PRECAUTIONS

ALL ELEMENTS

CHECK THE BELT SYSTEM AND THE LEASH BEFORE USING BOTH PRODUCTS





## Special precautions!

This belt system is permanently connected to humans & animals, so it requires special safety measures to minimise the risk of injury. Read these instructions before using your belt system and keep them for future reference. Train various situations with the belt system and your four-legged friend in advance in a secured environment so that you learn how to use the belt system. Due to the elastic sections of the leash, there is a risk that if the leash is torn off or the dog's harness is torn off, the leash and carabiner will snap back. The enormous force can cause serious damage to the eye, broken teeth, cuts and scratches! Only use mammo pet sports leashes in combination with the mammo 360° infinity belt system.

Here we go!

1. Check to ensure that the belt system & leash are in good, undamaged condition. If any parts of the belt system & leash are damaged, frayed or defective, do not use the belt system & leash.



2. First place the bottom belt around your hips and fasten it with the integrated velcro. Note that the velcro of the overlapping right side of the belt is between the first sliding element and the red seam (**Adjustment range per size**). If this is not possible, this size might not be suitable for you. The ergonomic back part must be centrally located in the back area and the pocket of the overlap strap in the upper area of the belt.



That is the right way!

That is the wrong way!



3. Now take the upper belt and first loosen the velcro fastener and, if necessary, also the magnetic fastener. Insert the upper belt with the **thin tongue end from left to right** into the sliding elements of the bottom belt and guide the tongue of the upper belt into the opening provided for this purpose on the other side of the upper belt. (See instruction label)



4. Now connect the two parts of the magnetic fastener and make sure that the straps are not twisted. Now hold the small, luminescent green loop with your right hand (ATTENTION: If you pull on the red strap, the magnetic fastener will come loose) and close the velcro along the upper belt to the left while pulling with your left hand.



5. Now turn the upper belt by 180° so that the loop with the leash connection is on your front side. In order to be able to determine the optimum setting of the upper belt, turn the loop of the leash connection into the position of a sliding element and pull strongly on the loop (TIP: You can hook the leash into the loop in advance). Each sliding element is marked with the word „MAX“ and a limit line when you look at the sliding element from above. If the upper belt can be pulled beyond this line, the Velcro fastener of the upper belt must be tightened, otherwise there is a risk that the upper belt will slip out of the sliding area. If the upper belt is in the „MAX“ range, the adjustment is correct. In this range, you choose for yourself which is the optimal setting for your needs. The closer the upper belt moves to the „MAX“ limit, the easier it turns around the bottom belt.



Limit line!



6. Now attach the carabiner of the leash to the loop provided or to the Panic Snap, which is available separately. (NOTE: We recommend the additional use of a quick release (Panic Snap\*) between the loop of the upper belt & the carabiner of the leash. Attach the other end of the leash to the dog's harness. (NOTE: The belt system may only be used in combination with a dog harness - Not suitable for use in combination with collars!)



\*The quick release (Panic Snap) offers an **additional possibility** to separate the leash from the belt even under tension in dangerous situations.

## Emergency release for dangerous situations



The magnetic fastener on the upper belt with the red strap provides a fixed emergency opening for dangerous situations. When you pull the red strap off your body, the upper belt opens and is released from the bottom belt by the pull of the leash. This may also be done if you want to release the upper belt from the bottom belt normally after your activity.



#### LIMITED WARRANTY

The manufacturer's warranty for mamopet sports products is valid for two years commencing with the date of purchase. If the item is an original manufacturer's product, the limited warranty exclusively covers defects in respect to the material and process. In the event of a defect, please return the leash to the seller or send it to the address stated below enclosing the proof of purchase. This limited warranty does not cover defects caused by dogs themselves, such as torn, defective leash straps caused by dog chewing, or any other defects, due to abuse, mishandling or wear and tear.

#### REPAIRS

Do not try to repair or modify the leash in any way. Any independent repairs, modifications or adaptations will invalidate the warranty claims (see item „Limited warranty“).



Let's talk ... we'll be happy to answer your questions!



[office@mamo.at](mailto:office@mamo.at)

**FREUND  
DERBERGE**

mamopet sports e.U.  
Peter-Tunner-Straße 19  
A-8700 Leoben

[www.mamopetsports.com](http://www.mamopetsports.com)

 **mamo**  
pet sports